


<b>APPROACH CHART</b>	ALT IN <b>FEET</b>	OBST NOT SHOWN	NORWAY CONTROL 126.45	ENGELØY TRAFFIC 123.50	<b>ENGELØY ELVIK NORWAY</b>
FIGURES NOT TO SCALE	TA 7000	VAR 6.3° E (2018)			



<p><b>Warnings</b></p> <ul style="list-style-type: none"> <li>• Windshear and difficult flying condition is reported when wind from sector east to south.</li> <li>• Radio controlled model flying and other activities may occur at aerodrome.</li> </ul>	<p><b>Local rules</b></p> <ul style="list-style-type: none"> <li>• All use of the RWY must be authorized in one of the following ways: 1) Complete the check form at <a href="https://utsjekk://engeloyflyplass.no">utsjekk://engeloyflyplass.no</a> or 2) Get oral/written approval from the airfield staff.</li> <li>• Transmit on ENGELØY TRAFFIC in the radius of 10 nm at or below 3000' MSL.</li> <li>• Listen on NORWAY CONTROL if whenever possible due to transit traffic.</li> <li>• To be used between 0700-2300 local time only.</li> </ul>
--	---

**REMEMBER TO CLOSE FLIGHTPLAN**  
**(TEL +47 64819000)**