


APPROACH CHART	ALT IN FEET	OBST NOT SHOWN	NORWAY CONTROL 126.45	ELVIK TRAFFIC 123.50	ENGELØY ELVIK NORWAY
FIGURES NOT TO SCALE	TA 7000	VAR 6.3° E (2018)			



<p>Warnings</p> <ul style="list-style-type: none"> • Windshear and difficult flying condition is reported when wind from sector east to south. • Radio controlled model flying and other activities may occur at aerodrome. 	<p>Local rules</p> <ul style="list-style-type: none"> • All use of the RWY must be authorized in one of the following ways: 1) Complete the check form at utsjekk://engeloyflyplass.no or 2) Get oral/written approval from the airfield staff. • Transmit on ELVIK TRAFFIC in the radius of 10 nm or at below 3000' MSL. • Listen on NORWAY CONTROL if whenever possible due to transit traffic. • To be used between 0700-2300 local time only.
--	---

REMEMBER TO CLOSE FLIGHTPLAN
(TEL +47 64819000)